

USER MANUAL

Limited Warranty

JS Speaker Technology LLC guarantees the UM-1 to be free of defects for the product's warranty period of 5 years.

The warranty period begins on the original date of shipping. The limited warranty is intended only for the original purchaser. The warranty will be void if the bracket is modified in anyway or not installed correctly, Including overloading, abuse, or use for any purpose other than specified in these directions. The UM-1 is for indoor use only and any use outdoors will void this warranty.

JS Speaker Technology LLC is not liable for any damage or injury caused from the use of or the inability to use our bracket. To the maximum extent permitted by applicable law, JS Speaker Technology, LLC disclaims any responsibility for incidental or consequential damages.

Additional terms and limited warranty conditions that apply to this product are listed on the Next Level Acoustics website at:
www.nextlevelacoustics.com/warranty.

Next Level UM-1 Bracket

Thank you for purchasing the UM-1 mounting bracket. Please read the directions thoroughly and plan how the mount would be best installed for its intended use. Failure to do so may result in Damage, Personal Injury, or voiding the warranty. It is the installer's responsibility to ensure all components are properly installed. JS Speaker Technology LLC is not responsible for any damage or injury resulting from improper mounting or use of the UM-1 bracket.

These instructions are only a guide and the installer is responsible for the correct and secure mounting of all associated products. Please follow all manufactures instructions for any product being installed with the UM-1 bracket. Please note: Each Setup will be different and these directions may not account for every situation. The person installing the bracket should have experience mounting load bearing assemblies. For any questions or concerns, please contact technical support at Next Level Acoustics at 617-237-2875 or info@nextlevelacoustics.com.



CAUTION: The UM-1 is intended for use only within the maximum weights **denoted below**. Use with heavier than the maximum weights indicated may result in instability causing possible serious injury or damage. Review all relevant manuals to ensure that the setup can handle the load.

- **12-15 lbs.** when mounting above the TV using the stock TV stand (max weight varies depending upon how wide the stock TV base is)
- **12-20 lbs.** when mounting above the TV in conjunction with a TV mount
- **30 lbs.** when mounting below the TV in conjunction with a TV mount

DISCLAIMER: Maximum weight measures are only guidelines and **ARE NOT** absolute! Use precaution when mounting.

Specifications

- Shipping Dimensions: 22" x 4" x 4"
- Shipping Weight: 4 lbs.
- Bracket Weight: 3 lbs.

Parts Included

- (1) UM-1 Bracket Assembly (Sandwich, Vertical, Depth)

Hardware Included

- (4) #10 Nuts and (4) 1/4" Nut
- (4) #10 Bolts and (4) 1/4" Bolts
- (4) #10 5/8" Screws and washers (mounting to Elite and Fusion products)

PLEASE READ: May require spacers between the UM-1 and TV mount when using lower profile mounts (**sub 2.75" from wall to back of the display**) due to the increased depth adjustment capabilities of this bracket system

Mount Uses


- The UM-1 is designed and tested to mount Fusion Series Soundbars and Elite Enclosures below the TV when using a TV mount all within weight guidelines
- The UM-1 may be used to mount an Elite Enclosure or Fusion Series Soundbar above the TV, but proceed with **extreme caution** ensuring that the enclosure or soundbar is adequately secured to the bracket and is stable to avoid damage or injury

How to build the UM-1 Bracket System


- Assemble the UM-1 following the Figure 1 Bracket Setup diagram below using the provided parts and hardware
- **Please note:** There are left and right side parts to this assembly (Vertical Support/Depth Support)

Depth Adjustments

- Choose the proper depth adjustment permutation to perfectly line up the Center Speaker, Soundbar, or Enclosure with the top or bottom edge of the TV




****You can also swap the Depth Supports to the other side of the bracket to achieve different anchor points****



Tilt Adjustments

- Choose the proper tilt adjustment angle to perfectly line up the Center Speaker, Soundbar, or Enclosure with the top or bottom edge of the TV



Mounting Basic Recommendations

- **Elite Series Below the TV**—Secure to the UM-1 Bracket Depth Support using two per bracket #10 5/8" long screws and associated washers per bracket (included)
- **Fusion Series Soundbars Below the TV**—Drill a pilot hole and secure to the UM-1 bracket Depth Support using two #10 5/8" long screws and associated washers per bracket (included)

When mounting an Elite Enclosure or Fusion Series Soundbar above the TV use **extreme caution** ensuring that the enclosure or soundbar is adequately secured to the UM-1 bracket to avoid damage or injury

Attaching to the TV


When using the TV manufacturers stand

- Determine the optimal bracket placement and line the Sandwich support's oval holes with the threaded holes on the back of your TV. Secure the Sandwich Support to the back of the TV using the TV manufacturer's recommended hardware
- If your TV has bump outs, spacers may be needed. (Spacers are not included)


When mounting the TV to the wall

- Mount the Sandwich Support between the TV Mount and the TV. Make sure all 4 screws/bolts go through the Sandwich Support and anchor snugly into the threaded holes on the back of the TV. Spacers may be needed if the Sandwich Support interferes with the TV Mount. For most dual hanger style TV brackets spacers will not be needed
- If your TV has bump outs, spacers may be needed. (Spacers are not included)


**** Before mounting, consult your TV's owner manual / TV mount's manual and follow all safety precautions.**



Mounting above the TV example



Mounting below the TV example





NEXTLEVEL
A C O U S T I C S

UM-1 BRACKET