



CUSTOM INSTALLER SERIES

RAIL INSTALLATION

Rail Installation

- 1) Remove the speaker from the packing materials and the foam shipping blocks from the wood rails. On larger models when instructed to leave the foam blocks intact please do not remove. These foam blocks are used to support longer wingspan rail systems. The foam blocks will compress as you slowly hand tighten. (see instruction #7)

- 2) Using the provided wood template, cut a rectangular opening into the desired section of the wall. Push any fiberglass insulation aside while keeping as much as possible within the opening to allow the speaker to easily fit into the opening



Fig. 1

- 3) Remove the speaker grille and loosen the front panel bolts, 2 - 3 turns only counterclockwise (See Fig. 1)

- 4) Slide the bottom end of the speaker into the wall until the bolts are resting on the openings bottom edge (See Fig.2)




Fig. 2

- 5) Connect the wires to the spring terminals located on the back of the speaker

- 6) Push the speaker assembly into the top section of the opening allowing the top ends of the rails to slide behind the top of the wall. Lift the bottom edge of the speaker until the frame is FLUSH with the wall on all four sides (See Fig. 3)




Fig. 3

- 7) Tighten the four front panel machine screws by hand clockwise until the rails catch and securely engage the back of the drywall. Tighten each screw a few turns going around the speaker in order to apply even force to the back of the speaker. Do not use a drill! (See Fig. 4)




Fig. 4

- 9) Replace the grille